www.sqa.ca

- Install bottom guide in left and right corners by placing hook **A** in stile.
- Rotating guide until tap **B** enters notch in rail and tap **C** enters notch in stile.
- Press bottom nylon guides down with thumb until guides snap into bottom track.

Guides will compensate for for uneven floor.

To remove, insert screwdriver between guide and track and pry out.

Note:

If stile has been cut down, break off fastening clip **D** using pliers, drill hole and screw into stile **E**.

